

RCA PHONO

RCA Plug

SP116RC
Ø 7.5mm



SP116G-C81-BK (Black)
SP116G-C81-RD (Red)
Ø 6mm




SP117A-1-BK (Black)
SP117A-1-RD (Red)
SP117A-1-BL (Blue)
SP117A-1-YL (Yellow)
Ø 5.5mm



RCA Jack


SJ214-BK (Black)
SJ214-RD (Red)
Socket



SJ216G-C81-BK (Black)
SJ216G-C81-RD (Red)
Ø 6mm



SJ216A-1-BK (Black)
SJ216A-1-RD (Red)
Ø 5.5mm



Molded RCA Adaptor

SA177
6.35mm TRS Plug
to RCA Jack*2



SA178
6.35mm TS Plug
to RCA Jack*2



SA179
3.5mm TRS Plug
to RCA Jack*2



SA178Y
6.35mm TS Plug
to RCA Jack*2



SA154
6.35mm TS Plug
to RCA Jack



SA153
3.5mm TS Plug
to RCA Jack



Metal Adaptor

SA134
6.35mm TS Plug
to RCA Jack



SA181
RCA Plug
to RCA Jack*2



SA181Y
RCA Plug
to RCA Jack*2



SA157-3
RCA Jack*3
to RCA Jack*3



SA157-2
RCA Jack*2
to RCA Jack*2



SA157
RCA Jack
to RCA Jack




Fuse Holder

Max AC 250V 10A


Small Type **SF372S**
Use Fuse
Ø 5.2*20mm



Large Type **SF372**
Use Fuse
Ø 6.4*30mm



SF372S



SF372